



Collection points and specialist retailers








Standard containers

collecting and transporting

- Electrical and electronic appliances must be placed in the specified container. Deviations are possible in consultation with the SENS recycling company.
- The fill height for pallets with frames or post pallets is limited. The containers must be filled in such a way that the waste electrical and electronic equipment cannot fall out.
- The sides and base must be sufficiently sealed.
- Electrical and electronic appliances must be secured to the pallets for transport using the appropriate aids.

Correct



Standard container	Purpose of use	Empty container
EU pallet (exchangeable)	Large appliances Refrigerators PV modules	
EU pallet with frames (exchangeable)	SENS products by kg	
Post pallet with insert (exchangeable)	Lighting equipment, rod-shaped 50 to 150 cm	
Two-frame EU pallet (exchangeable)	Lighting equipment, rod-shaped 50 to 150 cm	
SENS lighting equipment bag (disposable)		
Collection box long (disposable)	Lighting equipment, rod-shaped 50 to 150 cm	
Collection box small (disposable)	Lighting equipment, non-rod-shaped	
Collection container	Broken lighting equipment	

Contact

If you have any questions,
please contact
SENS eRecycling.

+41 43 255 20 00
info@eRecycling.ch

www.eRecycling.ch

The “collection and transport” information sheets for collection points and specialist retailers apply.